

Remove steering wheel,
refer to 32 33 000

Remove panelling for instrument panel at bottom,
refer to 51 45 180



Unfasten screws, then slide instrument cluster straight out of trim and fold over.

Caution!

Place cleaning rags on steering column to avoid scratches in glass of instrument carrier.



Push levers on connectors forward and take out connectors.

Installation:

When inserting a connector, lever must be in forward position.

Recode instrument carrier after replacing. Refer to IDC 003/92-14

Installation:

Convert and reset encoding connector when replacing instrument carrier,

refer to 62 10 000

Tests 15 and 09